






Chair Liftor Space








Importer:
Liftor s.r.o.
Pod Vinicemi 931/2, 301 00 Plzeň
www.liftor.cz

V6 spare part list

				
casters 5pcs	Base 1pcs		headrest 1pcs	Air rod 1pcs	wrench 1pcs
					
	Armrest 1 pair	backframe spacer 3pcs	Backframe screws (M8*45) 3pcs	Chassis screws (M6*25) pcs	
					
Backframe 1PCS	Armrest screws (M6*30) 6pcs	Screws spacer 10pcs	seat cushion 1pcs	Mechanism 1pcs	

V6 Installation guide

		
1.Insert the casters into the chair base hole 5pcs	2.Put the air rod into the center of the chair base .	3. Install armrest , screws (M6*30)+Spacer
			
4. Install the mechanism, Screw (M6*25) 4pcs + spacer	5. Install the backframe with seat cushion , Screw (M8*45) 3pcs + spacer 3pcs	6.connect the seat cushion with air rod	7.Insert the headrest to the backframe